

Filters: Medical/Laboratory

Medical/lab inlet vacuum filters remove liquids, solids, and sub-micron particles. The ULPA media complies with HTM2022 & BS3928:1969 efficiency levels – 99.99% @ 0.12 microns. The filter housing features a cast aluminum head with integrated baffle, as well as a high impact see-through bucket. At the base of the bucket are a brass valve and fitting for contaminated liquid release and a removable and sterilizable drain flask.



Part #	233907	233908	233909	233911	233912	233913	233914
FPT Inlet/Outlet Connections	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"	4"
Nominal Rating SCFM	41	41	41	102	102	200	200
Approx. Weight (lb)	15	14	14	20	19	33	29
Replacement Element	233940	233940	233940	233941	233941	233942	233942