

Control Modules for Vacuum Pumps and Compressors

Flexibility of operation with superior motor protection is provided by this line of control modules. Four sizes handle a range of 0 to 40 amps, accepting voltages from 208 to 600VAC. The module features variable overload selection, and several motor protection features:

- Predicts a safe operating range by monitoring motor inrush conditions
- Trips and alarms if the starter needs to be calibrated
- Protects against extended starting times, locked rotor, and stall conditions
- Prevents motor damage due to setting overload above acceptable limits

The module is automation compatible with dry and wet inputs, relay outputs and 24 VDC output. The module mainframe includes multiple top and bottom knockouts, and a lockable service cover. UL Type 1 indoor enclosure.



Part #	200V 3-phase	230V 3-phase	460V 3-phase	600V 3-phase	SCIC KAIC @ 460V	NEMA Size
214015	1 HP	1.5 HP	3 HP	7.5 HP	5	0
214016	3 HP	5 HP	10 HP	15 HP	5	0
214017	7.5 HP	10 HP	20 HP	30 HP	5	1
214018	10 HP	10 HP	30 HP	30 HP	5	1P