

# Filters: Integrated Liquid Separators

Combination Liquid Separator/Vacuum Filters are designed for challenging applications with liquids in the process stream. They serve the dual purposes of knocking out liquids and filtering particulates. The filter has an integrated baffle mechanism and removable polyester filter element that is 99+% efficient to 5 microns. The housing, constructed of carbon steel with epoxy coating, houses a 1" sight port and a 1" drain port.



Part #	233932	233933	233934	233935	233796	233797	233798	233799	233910
<b>FPT Inlet/Outlet Connections</b>	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"	4"	6"
<b>Nominal Rating SCFM</b>	60	85	85	100	135	195	300	520	830
<b>Canister Height (in)</b>	17	17	18	18	22 1/4	24 3/8	25 1/8	24 3/8	40 1/2
<b>Canister Width (in)</b>	7 3/4	7 3/4	7 3/4	7 3/4	12	12	12	16	16
<b>Approx. Holding Capacity (gal)</b>	1.5	1.5	1.5	1.5	2.5	2.5	2.5	4.5	4.5