

Filters: Clear Liquid Separators with Float

See through liquid separators are ideal for protecting vacuum pumps from liquids and large particulates. They feature a “T” style cast aluminum lid with integrated knock-out baffle and a high impact polycarbonate bucket for easy visual inspection. All models include a bottom mounted 1/2” drain, as well as 1/4” differential gauge ports. Large particulates are filtered by a 50 mesh 304SS separator screen. Inside the screen is a float ball, which blocks flow to the pump when the canister level is full.



Part #	233937	233938	233939	233792	233793	233794	233795
FPT Inlet/Outlet Connections	1”	1 1/4”	1 1/2”	2”	2 1/2”	3”	4”
Nominal Rating SCFM	68	102	136	297	356	510	850
Cannister Height (in)	13 3/8	13 3/8	13 3/8	16 1/4	16 1/4	19 3/4	19 3/4
Cannister Width (in)	7	7	7	9	9	13 1/2	13 1/2
Approx. Holding Capacity (gal)	0.4	0.4	0.4	1	1	2	2