

# Mechanical Seals for Liquid Ring Vacuum Pumps

Versatile mechanical seals are applicable for most liquid ring vacuum pumps, fitting into a variety of envelope dimensions. Featuring stainless steel metal components, each seal has viton elastomers, a carbon rotating face, and a Ni-resist stationary face. A rubber friction ring prevents the seal from sliding on the shaft, eliminating shaft fretting. Simple in design, the seal can be rotated in either direction, as the spring merely provides axial load.



Model	28 mm	35 mm	38 mm	43 mm	55 mm
Part #	221430	221431	221432	221433	221434